



### RLCB Installation

This guide provides installation instructions for the Rear Lower Crossover Brace.

#### Tools Required

Ratchet, 12mm Socket, 14mm Socket, Torque Wrench

#### Installation Notes

It is best to have the car on a flat, level surface for the installation of this brace. Ideally, the car should be placed on jack stands. You do not want to install bracing with the car jacked up from one side.

#### Steps

1. Remove the brake line from each stock dog bone brace using a 12mm socket (2 places.)



2. Remove the bolts from each dog bone brace using a 14mm socket (2 places.)



3. Put the RLCB in the position as shown below & hand tighten the 4 bolts to hold it in place. However, unlike the picture, the brake line goes on top of the brace as it did on the stock dog bone brace (thus the threaded hole.)



4. Snug the installation bolts using a 14mm socket (4 places.)

5. Attach the brake lines to the RLCB & snug using a 12mm socket (2 places.)

6. Torque the dog bone mounting bolts to 28 ft/lbs (4 places.)

7. Torque the brake line bolts to 14 ft/lbs (2 places.)



### Typical order of Installation

1. FSTB
2. RSTB
3. BP or MSMB
4. FMB
5. RLCB
6. RMB

Disclaimer: Proper service & repair procedures are vital to the safe, reliable operation of all motor vehicles as well as the personal safety of those performing the repairs. Standard safety procedures & precautions (including use of safety equipment & proper tools) should be followed at all times to eliminate the possibility of personal injury or improper service which could damage the vehicle or compromise its safety. Although this material has been prepared with the intent to provide reliable information, no warranty (express or implied) is made as to its accuracy or completeness. Neither is any liability assumed for loss or damage resulting from reliance on this material. SPECIFICALLY, NO WARRANTY OF MERCHANTABILITY FITNESS FOR A PARTICULAR PURPOSE OR ANY OTHER WARRANTY IS MADE OR TO BE IMPLIED WITH RESPECT TO THIS MATERIAL. In no event will Corky & Co., llc. or its affiliates be liable for any damages, direct or indirect, consequential or compensatory, arising out of the use of this material.

THE INFORMATION, PRODUCTS, MATERIALS & SERVICES CONTAINED IN THIS DOCUMENT, INCLUDING WITHOUT LIMITATION, GRAPHICS, TEXT & LINKS ARE PROVIDED ON AN "AS IS" BASIS WITH NO WARRANTY OF MERCHANTABILITY FITNESS FOR A SPECIFIC USE OR REPRESENTATION OF ACCURACY.

Limitation of Liability: IN NO EVENT SHALL CORKY & CO., LLC. BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, PUNITIVE, CONSEQUENTIAL OR ANY OTHER DAMAGES WHATSOEVER, WHETHER IN ACTION OR UNDER CONTRACT, TORT OR OTHERWISE. Under no circumstance, including but not limited to, negligence, shall Corky & Co., llc. Be liable for any damages that result from the use of, or inability to use, the information, materials or products contained in or purchased from Corky & Co., llc. Further, Corky & Co., llc. shall have no liability or responsibility for any delay in the delivery, installation or use of the products, as well as the service life of the products, performance, crash worthiness, applicability for the use intended, proper installation, or the accuracy of information provided.